

3 Beeps

Turn off and on as required.

CPS – Optional Setting – Alert Tones


Alert Tone	
SMS Alert	None
Call Alert	None
Digi Call ResetTone	Off
Talk Permit	Off
Key Tone	Off
Idle Channel Tone	Off
Startup Sound	Off
Volume Change Prompt	Off
Key Sound Adjustable	Adjustable

Call End Prompt Box – On / Off

CPS – Optional Setting – Display

Display	
Brightness	5
Auto Backlight Duration	Always
Backlight Delay Of TX[s]	Off
Menu Exit Time[s]	30
Time Display	Off
Last Caller	Show Both
Call Display Mode	Call Sign Based
Call Sign Display Color	Red
Call End Prompt Box	Off
Display Channel Number	Actual Channel Number
Display Current Contact	On
Standby Char Color	White
Standby BK Picture	Default
Show Last Call On Launch	Off
Separate display	Off
CH Switching Keeps Last Caller	Off

Turn off STE CPS – Optional Setting – STE



Also change your Tones

Make your radio sound like a Motorola and other fun tone sequences to play with
<http://members.optuszoo.com.au/jason.reilly1/868mods.htm#TPTchirp>

<http://tiny.cc/Anytone-DMR>