

4000 Disconnect

Brandmeister 91 is a pig to get out off.

You need to do a **4000 Group Call**.

When you get a GAP in overs.

PTT for up to 5 seconds.

That will let the system see you want to leave.

You should always do a 4000 when moving to a new talk group.

If not the last talk group can still be live for up to 10mins.

4000 Does Not work on Static Talk Groups.

Videos

[Hotkey to send a TG4000 disconnect](#)

[6 ways to un-link](#)

<http://tiny.cc/AnytoneDMR>