


NXDN Roaming.


1. Make your NXDN channels for all the repeaters you want.
2. Add to a Zone
3. Open the Zone with your NXDN repeaters.

In this section I have only DMR repeaters as no NXDN repeaters in my area, but it would be the same for your NXDN repeaters.

You will see on the right a list of Split Frequency Repeaters.



Move across the NXDN Repeaters you wish to Roam.



4. Save Zone and send to radio.
5. Via the Radio go to the Zone you want.
6. Turn on Roaming

<http://tiny.cc/AnytoneDMR>