


Why you need a Windows PC

1. You **MUST** set the radio up via the Software “CPS”.
2. The CPS will only work on windows.
3. You can not run the radio without setting up all the **Optional settings**. There is no way round this. IT is a must.



4. Most Optional Settings can only be set via the CPS.
5. When you have done this and sent your code plug to the radio. **ONLY** then you can do some things via the radio.
6. If you make changes via the radio. You **MUST** read the radio back to the CPS, so you have them saved in your Code Plug.

You should look over this [website](http://tiny.cc/AnytoneDMR) for more info on how to setup.

<http://tiny.cc/AnytoneDMR>