

Working a Repeater via Manual Dial

You use the channel in your radio for lets say 2350.
You manual dial lets say TG 91.

You will stay on TG 91 depending on your Group Hang times settings (30mins or Infinity etc)

Now we have a 3rd party on the Repeater and they call 2350.
Your radio will drop TG91 and goes back to the default channel 2350

So if a repeater has 2350 as static or a users calls 2350, your radio will again go back to your default channel.

Be aware of this as you could be TXing on the wrong Talk Group.
Anyone say it 100% correct for the radio to do this.

Work around

When using manual dial via a repeater never use a Channel that is Static or Popular on the repeater.

Option

1. Make up a channel and use your DMR 7dig ID as a Talk Group.
This way the odds of another on the same repeater using your ID Talk Group is Zero.

Use that Channel for Manual Dial

<http://tiny.cc/AnytoneDMR>